







1	Engine part list		
No.	Part number	Name_English	Qty
1	R210	Engine	1
2	UG700-00026	Bolt - M8x45	4
3	UAE55-00052	Washer - 8	4
4	U455-00061	Washer - 8	4
5	U455-00053	Spring washer - 8	4
6	UG700-00022	Nut - M8	4

# 3 Chassis assembly




3 Chassis assembly parts list			
No.	Part number	Name_English	Qty
1	UA516-00009	Main frame weldment	1
2	UA516-00010	Limit device	1
3	UA516-00011	Partition	2
4	UA516-00012	Bolt - M10x50	3
5	UA516-00013	Pull spring	2
6	UA516-00014	Supporting frame of wheels	1
7	UA516-00015	Bolt - M14x90	2
8	UA516-00016	Wheel	2
9	U537-00111	Nut - M10	10
10	U455-00029	Washer - 10	11
11	UA516-00017	Partition 2	6
12	UA516-00018	Nut - M14	2
13	UA516-00019	Screw - M10x30	4
14	UA516-00020	Joint stick	2
15	UA516-00031	Partition 1	3
16	U455-00007	Nut - M8	1
17	U455-00061	Washer - 8	6
18	U537-00023	Bolt - M8x35	1
19	UA516-00021	Pressing frame weldment	1
20	UG700-00101	Bolt - M10x40	2
21	UG700-00100	Big washer - 10	2
22	UG700-00026	Bolt - M8x45	1
23	UG700-00022	Nut - M8	1
24	UA516-00022	Sproket frame	1
25	UA516-00023	Bolt - M10x100	1
26	UG700-00057	Check ring	1
27	UA516-00024	Bearing	1
28	UA516-00025	Sproket wheel	1
29	UA516-00026	Partition	2
30	UA516-00027	Weight Block	2
31	UA516-00028	Pressing plate of Weight Block	2
32	U537-00060	Bolt - M8x25	2
33	U455-00053	Spring washer	2
34	UA516-00029	Belt cover	1
35	UA516-00030	Nut - M10	2
36	UR200-00070	Spring washer - 10	2
37	U506-00064	Bolt - M8x20	1
38	UAE55-00062	Nut - M8	1

# 4 Tensional device



4 Tensional device parts list			
No.	Part number	Name_English	Qty
1	UA516-00032	Screw - M10x60	1
2	UA516-00033	Tensional Wheel	1
3	UAE55-00016	Bearing	2
4	UA516-00034	Partition I	1
5	UAE55-00017	Check ring	1
6	UA516-00026	Partition II	1
7	UT160-00022	Nut - M10	3
8	UAE55-00076	Hook	1
9	UA516-00036	Tensional Wheel frame	1
10	U455-00029	Washer - 10	4
11	UA516-00037	Bolt - M10x80	1


# 5 Front wheel






5 Front wheel parts list			
No.	Part number	Name_English	Qty
1	U506-00064	Bolt - 8x20	4
2	UV160-00085	Bearing	2
3	U455-00061	Washer - 8	4
4	UAE55-00062	Nut - M8	4
5	UA516-00038	Check ring	2
6	UA516-00035	Screw - M8x16	4
7	UA516-00039	Key - 6x60	2
8	UA516-00040	Front axle	1
9	UAE55-00041	Front wheel	2
10	UA516-00041	Front wheel partition	1
11	UA516-00042	Bolt - M8x20	1
12	UA516-00043	Sproket 2	1
13	US270-00059	Key - 6x25	1
14	UA516-00008	Bolt - M8x16	1

# 6 Forks group




6 Forks group parts list			
No.	Part number	Name_English	Qty
1	U506-00064	Bolt - 8x20	4
2	UA516-00045	Bearing	2
3	U455-00061	Washer - 8	4
4	UAE55-00062	Nut - M8	64
5	UA516-00046	Fork group	1
6	UA516-00047	Fixing braket	1
7	UA516-00048	Fork	24
8	UT160-00002	Bolt - 8x40	60
9	US270-00059	Key - 6x25	1
10	UA516-00049	Sproket 3	1
11	UA516-00008	Screw - 8x16	2

# 7 Big pulley



7			
Big pulley parts list			
No.	Part number	Name_English	Qty
1	U506-00064	Bolt - 8x20	4
2	UV160-00085	Bearing	2
3	U455-00061	Washer	4
4	UAE55-00062	Nut - M8	4
5	UA516-00051	Small sproket	1
6	UA516-00052	Chain	1
7	UA516-00053	Pulley shaft	1
8	UAE55-00023	Key - 6x30	1
9	US270-00059	Key - 6x25	1
10	UA516-00054	Big pulley	1
11	UAE55-00052	Washer - 8	1
12	U455-00053	Spring washer - 8	1
13	U537-00060	Bolt - 8x20	1
14	UA516-00055	Belt	1

# 8 Handle and controls



8 Handle and controls parts list			
No.	Part number	Name_English	Qty
1	UA516-00056	Big handle weldment	1
2	UA516-00057	Pin axls	2
3	U455-00032	Split pin	2
4	UG700-00095	Bolt - 8x30	2
5	U455-00061	Washer - 8	10
6	UA516-00058	Small handle sheath	2
7	UA516-00059	Small handle weldment	1
8	UG700-00026	Bolt - 8x45	1
9	UA516-00060	Partition	1
10	UA516-00061	Conneting rod	1
11	U455-00007	Nut - M8	4
12	UA516-00062	Bolt - M5x25	1
13	U506-00049	Washer - 5	2
14	UA516-00063	Nut - M5	3
15	U455-00006	Nut - M5	1
16	UA516-00064	Lower handle	1
17	UG700-00001	Big handle sheath	2
18	UA516-00065	Locking stick	1
19	UA516-00066	Grip	1
20	UA516-00067	Flexible pin	1
21	UA516-00068	Cable hook	1
22	UA516-00069	Tensional cable	1
23	UA516-00070	Tensional spring	1