






































POWER TRANSMISSION(BELT)



POWER TRANSMISSION(BELT)

No.	Parts No.	Name	Quantity	Note
1	63902-BA1-701	PULLEY, ENGINE	1	
2	91251-0835451	WASHER, RD 8×35×4.5	1	
3	93100-0802517	BOLT, FLANGE 8×25	1	
4	63400-BA1-804	STOPPER AL COMP, BELT	1	
5	63500-BA1-801	STOPPER AR COMP, BELT	1	
6	93100-0801617	BOLT, FLANGE 8×16	2	
7	63100-B96-002	PULLEY COMP, 203.2B	1	
8	97114-035141	KEY, 7×7×35SR	1	
9	91251-0835321	WASHER, RD 8×35×3.2	1	
10	93100-0802517	BOLT, FLANGE 8×25	1	
11	63903-B96-000	BELT W800, SB37	1	
12	65400-BA1-801	STOPPER D COMP, BELT	1	
13	93100-0801617	BOLT, FLANGE 8×16	2	
14	63200-BA1-002	PULLEY COMP, HST	1	
15	94101-06015	WASHER, PLAIN 6	1	
16	93100-0601617	BOLT, FLANGE 6×16	1	
17	91652-0207031	BELT RED S II, SA31	1	
18	65200-BA1-801	STOPPER B COMP, BELT	1	
19	93100-0801617	BOLT, FLANGE 8×16	1	
20	65904-B96-800	STOPPER E, BELT	1	
21	93100-0601217	BOLT, FLANGE 6×12	1	
22	48200-BA1-800	STAY COMP, CENTER COVER	1	
23	65901-BA1-800	STOPPER E, BELT	1	
24	94101-08015	WASHER, PLAIN 8	1	
25	93100-0802017	BOLT, FLANGE 8×20	2	

















