



## WM33

<b>WM33</b>			
<b>Номер</b>	<b>Артикул</b>	<b>Название</b>	<b>Кол-во</b>
1	WM00-00001	screw M5x25	2
2	WM00-00001	screw M5x15	2
3	WM00-00078	fuel tank housing	1
4	WM00-00079	fuel tank	1
5	WM00-00004	rubber gasket	4
6	WM00-00005	anti-drop plate	1
7	WM00-00006	sealing ring	1
8	WM00-00007	fuel tank cover	1
9	WM00-00080	filter fuel assembly	1
10	WM00-00081	semi-finished engine assembly	1
11	WM00-00082	top cover	1
12	WM00-00001	screw M5x20	1
13	WM00-00083	clutch drum	1
14	WM00-00041	circlip 35	1
15	WM00-00040	ball bearing 6202-2RS	1
16	WM00-00033	circlip 15	1
17	WM00-00084	clutch drum housing	1
18	WM00-00064	screw M6x25	4
19	WM00-00013	buckle	1
20	WM00-00107	rubber/ bump	1
21	WM00-00015	clamp	1
22	WM00-00064	screw M6x25 . Muffler	1
23	WM00-00064	screw M5x12	1
24	WM00-00041	circlip 45	1
25	WM00-00019	wire hold	1
26	WM00-00016	sleeve 26	1
27	WM00-00065	nut M5	1
28	WM00-00017	clamp	1
29	WM00-00064	screw M5x22	1
30	WM00-00018	harness clamp assembly	1
31	WM00-00019	wire hold	1
32	WM00-00065	nut M8	1
33	WM00-00020	left clamp	1
34	WM00-00064	screw M5x20	4
35	WM00-00021	lower clamp	1
36	WM00-00022	upper clamp	1
37	WM00-00023	plate washer 8	1
38	WM00-00024	knob	1
39	WM00-00048	bolt M8X65	1
40	WM00-00025	rubber	2
41	WM00-00026	right clamp	1
42	WM00-00001	screw M5x20	1
43	WM00-00085	muffler cover	1
44	WM00-00001	screw M5x15	1
45	WM00-00028	straight shaft assembly	1
46	WM00-00029	AL tubing	1
47	WM00-00030	rubber	6

## WM33

<b>WM33</b>			
<b>Номер</b>	<b>Артикул</b>	<b>Название</b>	<b>Кол-во</b>
48	WM00-00031	driver shaft	1
49	WM00-00032	gear box assembly	1
50	WM00-00033	circlip 10	1
51	WM00-00041	circlip 26	1
52	WM00-00040	ball bearing 6000-2z	2
53	WM00-00034	pinion	1
54	WM00-00035	gear box	1
55	WM00-00036	top guard	1
56	WM00-00037	screw M5x8	3
57	WM00-00040	bearing 6000-2z 10x26x8	1
58	WM00-00038	gear	1
59	WM00-00039	gear shaft	1
60	WM00-00040	ball bearing 6002-2z	1
61	WM00-00041	circlip 26	1
62	WM00-00042	OIL-SEAL 32x18x7	1
63	WM00-00043	axle sleeve	1
64	WM00-00044	blade retainer	1
65	WM00-00045	cap washer	1
66	WM00-00046	bottom guard	1
67	WM00-00047	flange nut M10x1.25 left	1
68	WM00-00064	screw M6x25	1
69	WM00-00064	screw M6x12	1
70	WM00-00048	screw M6x8	1
71	WM00-00049	control handle assembly	1
72	WM00-00064	screw M5x35	1
73	WM00-00050	plate washer 5	1
74	WM00-00051	plastic handle \ LH	1
75	WM00-00052	spring \ trigger	1
76	WM00-00053	lock trigger	1
77	WM00-00054	wire tube	1
78	WM00-00055	wire cable A	1
79	WM00-00056	wire cable B	1
80	WM00-00057	throttl cable assembly	1
81	WM00-00071	ST screw 3.5x9.5	1
82	WM00-00065	nut M5	1
83	WM00-00071	ST screw 4.2x10	3
84	WM00-00058	plastic handle \ RH	1
85	WM00-00059	spring \ trigger	1
86	WM00-00060	Adjusting rod	1
87	WM00-00061	trigger	1
88	WM00-00062	switch	1
89	WM00-00063	LH handle	1
90	WM00-00064	screw M5x45	1
91	WM00-00065	nut M5	1
92	WM00-00066	LH handle clamp	1
93	WM00-00067	AL tubing	1
94	WM00-00068	ST screw 4.8x19	1

## WM33

<b>WM33</b>			
<b>Номер</b>	<b>Артикул</b>	<b>Название</b>	<b>Кол-во</b>
<b>95</b>	WM00-00069	Strake of protective cover	1
<b>96</b>	WM00-00070	cutting blade	1
<b>97</b>	WM00-00071	ST screw 4.2x13	1
<b>98</b>	WM00-00072	guard	1
<b>99</b>	WM00-00073	clamp \ guard	1
<b>100</b>	WM00-00074	lock screw	1
<b>101</b>	WM00-00075	blade cover	1
<b>102</b>	WM00-00076	blade	1
<b>103</b>	WM00-00077	string head assembly	1