




Id	PartNo	Description	Quantity
E01-1	UST30-00001	Bolt M5*6mm	1
E01-2	UST30-00002	Rocker shaft	1
E01-3	UST30-00003	Valve rocker assy	2
E01-4	UST30-00004	Spark plug	1
E01-5	UST30-00005	Spring set, valve	2
E01-6	UST30-00006	Pusher	2
E01-7	UST30-00007	Valve spring	2
E01-8	UST30-00008	Crankcase	1
E01-9	UST30-00009	Intake valve	1
E01-10	UST30-00010	Exhaust valve	1




Id	PartNo	Description	Quantity
E02-1	UST30-00011	Respirator valve	1
E02-2	UST30-00012	Plate, respirator valve	1
E02-3	UST30-00013	Spring washer 3mm	1
E02-4	UST30-00014	Bolt M3x8mm	1
E02-5	UST30-00015	Gasket, bottom sealplate	1
E02-6	UST30-00016	Bottom sealplate	1
E02-7	UST30-00017	Bolt M5x55mm	4
E02-8	UST30-00018	Dipstick with seal	1
E02-9	UST30-00019	Pin	2
E02-10	UST30-00020	Crankcase assy	1
E02-11	UST30-00021	Bolt M5x20mm	6




Id	PartNo	Description	Quantity
E03-1	UST30-00022	Wind scooper assy	1
E03-2	UST30-00021	Bolt M5×20mm	2
E03-3	UST30-00024	Bolt M5×16mm	1
E03-4	UST30-00025	Cylinder cover	1
E03-5	UST30-00026	Gasket,cylinder cover	1




Id	PartNo	Description	Quantity
E04-1	UST30-00028	Oil seal, crankshaft(2)	1
E04-2	UST30-00029	Crankshaft & connecting rod	1
E04-3	UST30-00030	Woodruff key	1
E04-4	UST30-00031	Oil seal, crankshaft(1)	1
E04-5	UST30-00032	Piston ring set	1
E04-6	UST30-00033	Piston pin circlip	2
E04-7	UST30-00034	Piston	1
E04-8	UST30-00035	Piston pin	1




Id	PartNo	Description	Quantity
E05-1	UST30-00037	Side plate,crankcase(2)	1
E05-2	UST30-00038	Gasket,muffler	1
E05-3	UST30-00039	Muffler insulation pad	1
E05-4	UST30-00040	Fairing	1
E05-5	UST30-00041	Muffler assy(inner)	1
E05-6	UST30-00042	Muffler insulation pad	1
E05-7	UST30-00017	Bolt M5x55mm	2
E05-8	UST30-00044	Bolt M5x12mm	2
E05-9	UST30-00024	Bolt M5x16mm	1
E05-10	UST30-00046	Muffler cover	1




Id	PartNo	Description	Quantity
E06-5	UST30-00048	Flywheel assy	1
E06-1	UST30-00049	Ignition coil assy	1
E06-2	UST30-00021	Bolt M5x20mm	2
E06-3	UST30-00051	Nut,flywheel	1
E06-4	UST30-00052	Clutch assy	1
E06-6	UST30-00019	Pin	2
E06-7	UST30-00054	Flywheel cover	1
E06-8	UST30-00021	Bolt M5x20mm	4
E06-9	UST30-00056	Gasket	2
E06-10	UST30-00057	Clutch disc	2
E06-11	UST30-00058	Wave washer	2
E06-12	UST30-00059	Clutch bolt	2




Id	PartNo	Description	Quantity
E07-1	UST30-00061	Carburetor assy	1
E07-2	UST30-00062	Gasket,carburator	1
E07-3	UST30-00063	Bolt M5×35mm	2
E07-4	UST30-00044	Bolt M5×12mm	1
E07-5	UST30-00065	Side plate,crankcase(1)	1
E07-6	UST30-00066	Connecting block,carburetor	1
E07-7	UST30-00067	Bolt M5×75mm	2
E07-8	UST30-00068	Inlet gasket	1
E07-9	UST30-00069	Flameout switch	1




Id	PartNo	Description	Quantity
E08-1	UST30-00071	Air cleaner assy	1
E08-2	UST30-00072	Air filter element	1
E08-3	UST30-00073	Nut	2
E08-4	UST30-00074	Air block plate	1
E08-5	UST30-00075	Air filter body	1
E08-6	UST30-00076	Pipe	1



Id	PartNo	Description	Quantity
E09-1	UST30-00021	Bolt M5x20mm	4
E09-2	UST30-00079	Recoil starter assy	1
E09-3	UST30-00080	Starting flange	1
E09-4	UST30-00081	Fan	1



Id	PartNo	Description	Quantity
E10-1	UST30-00083	Fuel tank assy	1
E10-2	UST30-00024	Bolt M5x16mm	4



Id	PartNo	Description	Quantity
E11-1	UST30-00086	Washer, camshaft	1
E11-2	UST30-00087	Camshaft	1
E11-3	UST30-00088	Bottom rockshaft	2
E11-4	UST30-00089	Bottom rocker	2
E11-5	UST30-00090	Gasket, cam cover	1
E11-6	UST30-00091	Cam cover	1
E11-7	UST30-00092	Bolt M4×16mm	5